

AN-2107









Motion sensors in the restaurant public areas trigger the FP-ECC1 to switch on the system equipment power outlets. Continued activity in the seating areas will retrigger the FP-ECC1 to keep the system turned on. After a switch-selectable time period of 15, 30, or 60 minutes with no activity, the FP-ECC1 will turn off the system electronics. No operator intervention is needed to turn the system on or off.



Recommended Pwr. Supplies	
Product	QTY
PS-24AS 24 Vdc 500 mA	2*
RU-PA40D Power Supply	1, included

Line Color Key

	Line Level Audio Signal
	Loudspeaker Level
	Control Signal
	Video
	Mic Level Audio Signal
	Ground
	Power
	Miscellaneous